


PART NAME



HOW TO USE

- Check the battery state of charge inside the all-in-one microphone body and operate the power switch to use it.
- When the LOW BATTERY lamp lights up, connect the USB C TYPE charging cable to the main unit or charge it using the supplied charging cradle.
- When charging using the charging cradle, place the cradle charging pin on the body side of the charging terminal and check the status of the charging lamp. (Charging: Red, Full Charging : Green)
- Select the mode to suit your environment for use.
 - Volume : 3 levels volume (MAX-MID-MIN, Howling can occur when using the maximum volume in a small room with reflections)
 - Echo : Echo effect
 - Buzzer : 2-bit sound (Start sound within 1 second. After START sound output (more than 1 second), Attention bit sound switching).
- Connecting External Devices
 - MIC: Headset microphone connection (Unidirectional 3.5 pie)
 - AUX: Portable audio player output support with connecting 3.5pie stereo audio cable.
 - USB C: USB charging support

PRODUCT SPECIFICATION

PRODUCT NAME MICKER PRO **MODEL** MK-10W **RATED OUTPUT** 10W
FREQUENCY RESPONSE 200~15KHZ ± 2 DB **SIZE&WEIGHT** (H)260MM,
(W)300G **HOURS OF BATTERY USE** Approximately 6 hours for 7.4V
1100mAh Li-ion Battery **CHARGER** DC 5V 1A, USB C-type (2 and half
hours) **CERTIFICATION** NO MSIP-REM-EB3-MK-10W **CONFIGURATION**
Micker pro main body, Pouch, Strap, Charging Cradle, USB Charging cable
OPTION Unidirectional Headset Microphone (Sensitivity -40DB)

PROPER USE OF THE PRODUCT



Keep a suitable distance between the sound pick up part of the microphone and your mouth during use.



Keep the distance between the output of the lower speaker and the chest of the microphone at least 12cm.



Use the headset microphone to adjust the position of the microphone close to the mouth.



Do not cover the mesh of the microphone with your hand when using the microphone.



Do not use the speaker part of the microphone in a place near a table.



Howling may occur when using in a place where the reflection is severe or small space.

PRODUCT WARRANTY

The warranty period is one year from the date of purchase. Product malfunction or damage caused by user mistake may be excluded from our free product warranty and is subject to an extra charge for repair.

CAUTIONS

- Please make sure to fully understand the user manual before using the product.
- Use with caution since howling may occur when using the product in a small place.
- Beware that using the speaker near the ears of other person may cause hearing damage.
- For safety when charging, please use USB rated charging product (USB C TYPE DC 5V).
- Avoid using the product in high humid environment.
- If the product has been exposed to an environment with high humidity, dry it under a well-ventilated shade.
- If you do not use the product for a long time, the built-in battery may be discharged. Please, check charge status for use.
- Compatible products should be used when using headset microphones. Otherwise, howling may occur depending on the volume setting and location.
- Do not arbitrarily disassemble the product. Otherwise it may cause a product malfunction. Contact our customer service center if necessary.

micker

ALL IN ONE MIC

 **MICKER** PRO

Manufacturing Company	EBEST Co.,Ltd
Country of Manufacturing	Made in Korea
Product Name	MICKER PRO
Model Name	MK-10W
Rated Output Power	10W
Certification No	MSIP-REM-EB3-MK-10W



 **EBEST**

EBEST Co.,Ltd.
#705, World Meridian Venture Center 1,
254, Beotkkot-ro, Geumcheon-gu,
Seoul 153-781, Rep. of KOREA
T +82-70-4896-3782 F +82-70-8677-3787
www.e-best.co.kr

Mike? Just Micker!



 **MICKER** PRO
MANUAL